

ubiik	Weightless Starter Kit Ubiik Cloud User Manual	Version 1.0.9 Author Date..... 5/9/2018
-------	--	---

Weightless Ubiik Cloud User Manual

Revision History

Revision Code	Date	Description	Comments
1.0.0	Aug 16 2017	Initial Draft	
1.0.5	Sept 5 2017	Firmware 1.0.5	
1.0.7	Nov 11 2017	Firmware 1.0.7	Added Demo Applications data format
1.0.8	Jan 8 2018	Firmware 1.0.8	
1.0.9	May 9 2018	Firmware 1.0.9	

Table of Contents


Table of Contents	3
Account	5
Create account	5
Login	5
Logout	5
Reset password	6
Register Base Station	7
Activate Cloud Usage	9
Dashboard	10
Uplinks	11
Downlinks	12
Downlinks List	12
Send Downlink to an End Device	12
Send Firmware to an End Device	13
Send Downlink to a Multicast Group	13
Send Multicast Downlink	13
Send Multicast Firmware (via Downlink)	14
Base Station	15
Settings	15
Status	15
Read	15
Restart	15
Stop	15
Base Channel	15
Read	15
Set	16
Parameters	16
SIB	16
Blacklisted Channels	17
Multicast Groups	18
Create Multicast Group	18

Update a Multicast Group	18
Synchronize	19
End Devices	19
End Device	20
API	21
Token Authentication	21
GET Uplinks	21
Parameters	21
Response	21
POST Downlinks	22
Request Body	22
Response Body	22
Example	23
Request Body	23
Response Body	23
Demo Applications	23
Temperature and Humidity sample	23
RSSI sample	24
Contact	25

Account

Create account

Go to wpkit.ubiik.com/account/create/ and create an account using a valid email address.



The screenshot shows the 'UbiikCloud' account creation page. The title is 'Create a new Account'. It features an 'Email' input field with an envelope icon. Below it is a list of password requirements: 'Your password can't be too similar to your other personal information.', 'Your password must contain at least 8 characters.', 'Your password can't be a commonly used password.', and 'Your password can't be entirely numeric.'. There is a 'Password' input field with a lock icon, followed by a 'Password confirmation' input field with a circular arrow icon. At the bottom, there is a blue 'Register' button and a link that says 'I already have an account'.

Login

To login, go to <https://wpkit.ubiik.com/> or <https://wpkit.ubiik.com/account/login/>. Enter your username and password and click *Login*.



The screenshot shows the 'UbiikCloud' login page. The title is 'Login'. It features a 'Username' input field with an envelope icon and a 'Password' input field with a lock icon. Below the password field is a link that says 'I forgot my password'. At the bottom, there is a blue 'Login' button and a link that says 'I don't have an account'.

Logout

Once logged in, to logout click "Logout" on the menu.

Reset password

To reset your password, go to Ubiik Cloud login page (<https://wpkit.ubiik.com/account/login/>) and click on *I forgot my password*.




The image shows the UbiikCloud login page. At the top, the text "UbiikCloud" is displayed. Below it, the word "Login" is centered. There are two input fields: "Username" with an eye icon on the right, and "Password" with a lock icon on the right. Below the password field, there is a link that says "I forgot my password". At the bottom, there are two buttons: a blue "Login" button and a text link "I don't have an account".

Then, type the email you used to create your account and click on *Submit*.



The image shows the UbiikCloud "Reset your password" page. At the top, the text "UbiikCloud" is displayed. Below it, the text "Reset your password" is centered. There is a single input field containing the email address "myemail@company.com" with an eye icon on the right. Below the input field is a large blue "Submit" button.

You will receive an email with a link to restore your password. Click on the link and type and re type your new password. Click on *Submit*.




The image shows the UbiikCloud "Create a new password" page. At the top, the text "UbiikCloud" is displayed. Below it, the text "Create a new password" is centered. There is a list of four bullet points providing password requirements: "Your password can't be too similar to your other personal information.", "Your password must contain at least 8 characters.", "Your password can't be a commonly used password.", and "Your password can't be entirely numeric." Below the list are two input fields: "New password" with a lock icon on the right, and "New password confirmation" with a refresh icon on the right. At the bottom is a large blue "Submit" button.

Go back to the Login page and login with your new credentials.


Register Base Station

After creating an account or logging in, you will be redirected to the Dashboard, which will have no data to display yet.


Each kit includes a free 60-day license for cloud usage which commences counting from the date of registration. After this time you can choose to extend this license or continue using the kit with our Offline Tool.



Click on **Base Stations** on the menu.



Type the 32 characters Base Station ID provided. You can find it on the bottom of your Base Station. Click on **Register**.



Your Base Station has been registered but it is not pushing or receiving any data to or from the cloud.

Turn on your Base Station and connect it to the internet. Wait for up to 2 minutes for the Base Station to boot and register to the cloud.

At this point you can start using the Offline Config Tool.


Activate Cloud Usage

If you want your Base Station to push/receive data to/from the cloud, and to see if it is online or offline, you need to activate the cloud usage.

In order to do this, click on the **See More** button corresponding to the Base Station to activate to go to the Base Station Detail page.



Click on **Activate Cloud Usage**.




Cloud usage is active now and you are able to receive uplinks, send downlinks and configure your base station from the cloud.

To deactivate the cloud usage, click on **Deactivate**.

Dashboard

This view displays a summary of your account. You can see the list of Base Stations and End Devices and their current status.

In this page as in the rest of the website, all times are in UTC.



You can also see Uplink and Downlink traffic, which is sampled every 10 seconds.



Uplinks

To access this view click on **Uplinks** on the menu. You will see a list containing the Device ID, Base Station, Data, and time at which the event happened.

The Device ID, Base Station and Data are encoded in base 16.

If you are writing your own application, this view is useful to validate that the data is being sent correctly.

The list is limited to the latest 100 uplinks and can be sorted by each column.

ID	Device (HEX)	Base Station (HEX)	Data (HEX)	Date	Mode
210	03f41dece118c68ef2b3b5a37527bc01	0427c155f2bae8b9b8d8301867f50cc5	01420c23	2017-08-14T09:35:19.100Z	Unacknowledged
209	03f41dece118c68ef2b3b5a37527bc01	0427c155f2bae8b9b8d8301867f50cc5	013d0c23	2017-08-14T09:35:11.101Z	Unacknowledged
208	03f41dece118c68ef2b3b5a37527bc01	0427c155f2bae8b9b8d8301867f50cc5	013e0c23	2017-08-14T09:35:08.034Z	Unacknowledged
207	03f41d9fca515481419f7ea29e948201	0427c155f2bae8b9b8d8301867f50cc5	01590c21	2017-08-14T09:35:07.101Z	Unacknowledged
206	03f41dece118c68ef2b3b5a37527bc01	0427c155f2bae8b9b8d8301867f50cc5	013d0c23	2017-08-14T09:34:59.100Z	Unacknowledged
205	03f41dece118c68ef2b3b5a37527bc01	0427c155f2bae8b9b8d8301867f50cc5	01390c23	2017-08-14T09:34:52.078Z	Unacknowledged
204	03f41d9fca515481419f7ea29e948201	0427c155f2bae8b9b8d8301867f50cc5	01540c21	2017-08-14T09:34:51.100Z	Unacknowledged

Downlinks

Downlinks List

To access this view click on **Downlinks** on the menu. You will see a list containing the Device or Multicast Group ID, Data, and time at which the downlink was sent.

The Device ID, Base Station and Data are encoded in base 16.

The list is limited to the latest 100 downlinks and can be sorted by each column

Downlinks [Downlinks Summary](#)

Downlinks

ID	Device / Multicast Group (HEX)	Data (HEX)	Date	Mode
37	0bae8dc0c05b44e64045587461e1cf75	8405	2017-08-11T08:44:03.767Z	Acknowledged
35	0bae8dc0c05b44e64045587461e1cf75	8405	2017-08-11T08:43:30.934Z	Acknowledged
33	0ef41da316e739867d508da242559f01	8407	2017-08-11T06:49:03.673Z	Acknowledged
31	0ef41da316e739867d508da242559f01	8402	2017-08-11T06:48:19.164Z	Acknowledged
29	0ef41da316e739867d508da242559f01	8405	2017-08-11T06:46:40.419Z	Acknowledged
27	0bae8dc0c05b44e64045587461e1cf75	8404	2017-08-11T06:41:52.137Z	Acknowledged

Send Downlink to an End Device

After a device has connected to the Base Station, it will be listed in the Dashboard and the Base Station Detail page.

End Devices

UUID	Uplinks	Downlinks	Date connected	Last Activity
03A18D48DCEC292E0A188F4AB2A2F272	6319	0	2017-08-11 07:15:11 UTC	2017-08-14 09:19:20 UTC
03F41D9FCA515481419F7EA29E948201	6127	0	2017-08-11 07:15:55 UTC	2017-08-14 09:36:35 UTC
03F41DECE118C68EF2B3B5A37527BC01	1009	0	2017-08-11 07:13:32 UTC	2017-08-14 09:36:30 UTC
0BAE8DC0C05B44E64045587461E1CF75	1517	6	2017-08-11 06:36:51 UTC	
0EF41DA316E739867D508DA242559F01	18259	3	2017-08-11 06:45:44 UTC	2017-08-14 09:20:14 UTC

In order to send a downlink to an End Device, click on the device's UUID.

03A18D4BDCEC292E0A188F4AB2A2F272 End Device

Summary

Last Activity: 2017-08-14 09:19:20 UTC Base Station: 0427c155f2bae8b9b8d8301867f50cc5 Date Connected: Aug. 11, 2017, 7:15 a.m.
 Uplinks: 6319 Downlinks: 0

Send Downlink

Mode

Unacknowledged
 Acknowledged

Raw Data (HEX)

Raw Data (HEX)

Send

In the Device's detail page select if the downlink should be sent in acknowledged or unacknowledged mode and type your data in hexadecimal format. Click **Send** to send the Downlink.

Send Firmware to an End Device

You can also send a Firmware file (under 256KB) from this screen. In order to do this, scroll to *Send Firmware (via Downlink)*, click on *Choose File*, select a valid firmware file, and click on *Send*.

Send Firmware (via Downlink)

Firmware file:

firmware

Send

Send Downlink to a Multicast Group

Go to the Base Station detail Page and scroll down to the *Multicast Groups* section. In order to send downlinks to a Multicast Group, first you need to [create one](#).

Send Multicast Downlink

Scroll down to *Send Multicast Downlink*, select a Multicast Group previously created, select *Unacknowledged* or *Acknowledged* mode, type the data to send in Hexadecimal and click on *Send*.

Send Multicast Downlink

Multicast Group

Mode

- Unacknowledged
 Acknowledged

Raw Data (HEX)

8404

Send

Send Multicast Firmware (via Downlink)

Scroll down to *Send Multicast Firmware (via Downlink)*, select a Multicast Group previously created, click on *Choose File*, select a valid firmware file, and click on *Send*.

Send Multicast Firmware (via Downlink)

Multicast Group

Choose File firmware

Send

Base Station

To access this view, click on *Base Stations* in the menu and then click on *See More* under the Base Station you would like to work with.

This view allows you to see the status of the Base Station and to Configure it.

Once a command is sent, you won't see the result immediately. Since commands and responses are asynchronous and that the page auto refreshes every 10 seconds, it can take up to a minute to see the results appear on the page.

Settings

Status

Here you can see the status of the Protocol Stack

Status

Last Read Status: -----



Read

To read the status, click on *Read* and wait a few seconds to get the result.

Restart

To restart the Protocol Stack, click on *Restart*.

Stop

To stop the Protocol Stack, click on *Stop*.

Base Channel

The Base Channel is the channel (WARFCN) used by the Base Station to transmit and receive.

Base Channel

Last Read Channel: 8631

Read

Warning

Setting the Base Channel will cause the Base Station to restart. All End Devices connected must also be restarted and set to the new channel.

Base Channel

Set Channel

Read

Every time you read or set the Base Channel and the application receives a response, the *Last Read Channel* will be updated.

To read the current base channel, press *Read*.

Set

Setting the Base Channel will cause the Base Station to restart. All End Devices connected must also be restarted and set to the new channel.

To set the base channel, type a value between 1382 and 9297 and press *Set Channel*.

Parameters

For each parameter in the *Other Parameters* section, you can read the current value by clicking on *Read*. After reading, the label *Current Value* will be updated with the received value.

You can set a new value by typing it in the corresponding input and pressing the corresponding *Send* button. If the command is successful, the label *Current Value* will be updated with the selected value.

Under each parameter's name, you will find a list containing the allowed values and their meaning.

Other Parameters

NBFLAG (Current Value: 1)

0: wide band is used in UL | 1: narrow band is used in UL |

Read

Value

Set

SIB_MCS (Current Value: 3)

0: GMSK, 100Kbps, FEC OFF | 1: PSK, 12.5Kbps, FEC OFF | 2: GMSK, 50Kbps, FEC ON | 3: PSK, 6.25Kbps, FEC ON |

Read

Value

Set

NBFLAG

SIB_MCS

UL_MCS

UL_MCS_NB

ED_MCS_CTRL

ED_TX_PWR_CTRL

SIB

In this view you can see and change part of the System Information Block.

To see the current SIB status, click on *Read SIB* and wait for the values to be refreshed.

If *Frequency Hopping* is not enabled, the fields *First Hopping Channel*, *Channel Spacing*, and *Number of Channels* will be empty.

SIB

Frame Duration 1

Enable Frequency Hopping Disabled

First Hopping Channel -

Channel Spacing -

Number of channels -

Read SIB

To change the SIB configuration, type in the values of each field and press *Write*. If you don't want to change the hopping configuration, leave the checkbox *Enable Frequency Hopping* unchecked.

Frame Duration 2 seconds

Enable Frequency Hopping

First Hopping Channel

First Hopping Channel

Channel Spacing

Channel Spacing

Number of channels

Number of channels

Set SIB

First Hopping Channel: First hopping Channel Number (WARFCN)

Blacklisted Channels

To blacklist a channel, type channel number (WARFCN) *Blacklist Channel*. This will add additional blacklisted channels to the existing channels.

Blacklisted Channels

1500

Blacklist Channel

Channel to remove from blacklisted channels

Allow Channel

To remove a channel from the Blacklist, type the channel number (WARFCN) in the second input and press *Allow Channel*.

Blacklisted Channels

1500

1600

Channel to blacklist

Blacklist Channel

1500

Allow Channel

Multicast Groups

Multicast Groups allow you to send Downlinks to multiple devices at a time.

Create Multicast Group

From the Base Station detail page, scroll to *Multicast Groups*. Type a Multicast Group Number and select at least one device from your list of End Devices. Finally click on *Send*.

Multicast Groups

Group ID	Devices
No data available in table	

Create Multicast Group

Devices

- 03F41D9FCA515481419F7EA29E948201
- 0EF41DA316E739867D508DA242559F01
- 03F41DECE118C68EF2B385A37527BC01
- 0BAE8DC0C05B44E64045587461E1CF75
- 03A18D4BDCEC292E0A188F4AB2A2F272
- 02F41DAF7A3C8F877193BDA22E959901

Send

Once the confirmation has been received from the Base Station, the Multicast Groups table will be updated

Group ID	Devices
1	3

Update a Multicast Group

To update a Multicast Group, click on the Group ID on the Multicast Groups table.

Multicast Groups

Group ID	Devices
No data available in table	

Create Multicast Group

Devices

- 03F41D9FCA515481419F7EA29E948201
- 0EF41DA316E739867D508DA242559F01
- 03F41DECE118C68EF2B3B5A37527BC01
- 0BAE8DC0C05B44E64045587461E1CF75
- 03A18D4BDCEC292E0A188F4AB2A2F272
- 02F41DAF7A3C8F877193BDA22E959901

Send

Check/uncheck the devices you want to add/remove and click on *Send*.

Synchronize

This command will send the Blacklisted Channels, Multicast Groups, SIB configuration and Base Channel as seen in the Cloud. This action will override the settings all the settings and since the Base Channel will be set, the Base Station will be restarted.

Base Station 0427c155f2bae8b9b8d8301867f50cc5

● Online

Devices connected/registered: 6

License Expiration Date: 2017-10-07 05:59:00 UTC

Uplinks: 49499

Last connection: 2017-08-15 06:18:05 UTC

Downlinks: 39

Synchronize

Deactivate Cloud Usage

End Devices

In the Base Station detail page, you can also see the list of End Devices that are sending Uplinks and receiving Downlinks through this Base Station.

Date Connected shows the first moment when the End Device connected to a Base Station and *Last Activity* will be updated every time an End Device connects, disconnects or sends an uplink.

End Devices

UUID	Uplinks	Downlinks	Date connected	Last Activity
02F41DAF7A3C8F877193BDA22E959901	884	0	2017-08-14 09:59:11 UTC	2017-08-15 04:04:45 UTC
03A18D4BDCEC292E0A188F4AB2A2F272	7719	0	2017-08-11 07:15:11 UTC	2017-08-15 04:54:32 UTC
03F41D9FCA515481419F7EA29E948201	7265	0	2017-08-11 07:15:55 UTC	2017-08-15 05:35:49 UTC
03F41DECE118C68EF2B3B5A37527BC01	7004	0	2017-08-11 07:13:32 UTC	2017-08-15 05:34:17 UTC

To access the End Device detail page, click on the End Device UUID.

End Device

You can see a list of all your End Devices from the Dashboard or a list of End Devices per Base Station from the Base Station detail page. In both cases, to access the End Device detail page, click on the End Device UUID.

In the End Device detail page, you can see a summary of the status of the End Device.

02F41DAF7A3C8F877193BDA22E959901 End Device

Summary

Last Activity: 2017-08-15 04:04:45 UTC Uplinks: 884	Base Station: 0427c155f2bae8b9b8d8301867f50cc5 Downlinks: 0	Date Connected: Aug. 14, 2017, 9:58 a.m.
--	--	--

Last Activity will be updated every time an End Device connects, disconnects or sends an uplink.

Date Connected shows the first moment when the End Device connected to a Base Station.

Base Station shows the last Base Station to which the End Device was connected to.

Uplinks shows the total number Uplinks sent from this End Device and *Downlinks* shows the total number of Downlinks sent directly to it.

From this page, you can also [send downlinks](#) to the End Device. Please refer to the [Downlinks](#) section

Demo

This page displays *RSSI* and *Temperature and Humidity* samples from the applications preloaded in the End Device Modules. In order to get this applications running, please see *Weightless SDK: Getting Started*.

This is a *live* view meaning that data will be displayed as it is received.

GPS

Same as for the previous demos, if you have a Ubiik GPS end device, once it has successfully acquired a GPS fix, this page will display a marker for each fix received.

This is a *live* view meaning that only fixes that are sent after the page is open will be displayed.

Also, markers will be displayed after at least one *Full Fix* has been received. For more information regarding GPS, please see the *GPS User Manual*.

API

The API allows you to GET uplinks and POST downlinks. It uses Token Authentication. Times are in ISO format: YYYY-MM-DDTHH:MM:SSZ and must be URL encoded. Base Station ID must be sent in base64 URL Safe Alphabet¹

Token Authentication

You can get your token, go to the *API* section of Ubiik Cloud. When sending a request, set the **Authorization** header to "Token YOUR_TOKEN"

GET Uplinks

URL: `wpkit.ubiik.com/api/uplink`

Parameters

All parameters are optional

- `base_station`: Base Station ID in (Base64 URL Safe)
- `from_time`: lower bound for event time (time in which the message was generated in the Base Station).
- `to_time`: upper bound for event time (time in which the message was generated in the Base Station).
- `from_server_time`: lower bound for server time (time in which the message arrived to the web server).
- `to_server_time`: upper bound for server time (time in which the message arrived to the web server).

Response

The response contains a json array *data* with up to 100 uplinks:

```
{
  "server_time": Server time. String with format "%Y-%m-%dT%H:%M:%S.%fZ"
  "created": Event time. String with format "%Y-%m-%dT%H:%M:%S.%fZ"
  "ack": Acknowledge (true) or Unacknowledged (false) mode. Boolean,
  "edevic_id": End Device ID. String, Base64,
  "Basestation_id": Base Station ID. String, Base64
  "data": Uplink Data. String, Base64
  "id": Uplink Sequence number. Integer
}
```

¹ <https://tools.ietf.org/html/rfc3548>

Example

Request Body

```
{
  "target_id": "AQA=",
  "data":
"GwAAEQAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
AAAAAA",
  "ack" : true,
  "multicast" : true
}
```

Response Body

```
{
  "downlink": {
    "ack": true,
    "data":
"GwAAEQAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
AAAAAA",
    "multicast": true,
    "target_id": "AQA=",
    "id": 40
  }
}
```

Demo Applications

The End Devices come with two applications that can send samples via uplinks to the cloud. These two applications are *Temperature and Humidity* and *RSSI*. The following is the data format used in the uplinks.

Byte 0: Message Type

Byte 1 - N: Data

Temperature and Humidity sample

Byte 0: 0x01

Byte 1-2: Temperature (2 bytes, UInt16_t). In 100s of Celcius

(0x7FFF Invalid/Ignore value)

Byte 3: Relative Humidity (1 byte, byte). In percentage

(0xFF Invalid/Ignore value)

RSSI sample

Byte 0: 0x20

Byte 1-2: (2 bytes, Int16_t) Number of packets received in the period

Byte 3-4: (2 bytes, Int16_t) RSSI: Received Signal Strength Indication in dBm

Byte 5-8: (4 bytes, Int32_t) Internal use

Byte 9-12: (4 bytes, Int32_t) Internal use

Contact

General
info@ubiik.com

Sales:
jay@ubiik.com

END